

# 2010-2014 Padded Door Armrest Cover Instructions

Items needed:

- Double Sided Tape
- Alcohol
- Door armrest covers



1. Clean backside of door armrest covers with alcohol in the areas you will be applying the double sided tape
2. Once alcohol is dry, apply double sided tape along the edges of the door armrest cover, pressing firmly ensuring the tape bonds to the surface.



# 2010-2014 Padded Door Armrest Cover Instructions

3. Clean the factory door armrest of the car with alcohol and let dry completely



4. Peel the backing from the double sided tape



5. Align door padded armrest with factory armrest, pressing flat edge against the door and aligning the edges.



## 2010-2014 Padded Door Armrest Cover Instructions

6. Once aligned, press two together firmly and hold pressure for 10-15 seconds, allowing the tape to bond.

